


$$H_r = (H_c + 5B) / (B/M - 1) + H_c$$



$$H_r = (H_c + B) / (B/M - 1) + H_c$$



Phone: (916) 773 - 9766
 Fax: (916) 773 - 9764
 1588 Bedell Ct.,
 Roseville, CA 95747

Concrete Wall To Rock Wall Formulas

SCALE: None